

**FREEZER
INSTRUCTIONS
AND
WARRANTY**

General Instructions

Carefully examine the cabinet for shipping damage before discarding the packing material. If any damage is found, contact the delivery carrier immediately and have his agent prepare an inspection report for the purpose of registering a claim. THIS IS YOUR RESPONSIBILITY.

Positioning

The cabinet should be positioned on a flat surface. The cabinet must not be exposed to direct heat from radiators, sunlight or other sources of heat. The cabinet emits heat while it is running, and this heat is expelled through the body and the grating at the back or side of the cabinet. Consequently, there must be a gap of at least 100 mm (4") on the sides and back of the cabinet. If the cabinet is placed in a recess or placed beneath a working surface, etc., there must be a gap of at least 100 mm around and above the cabinet.

Use

Before using the appliance, it should be cleaned. A weak solution of soapy water is recommended. Scouring powder must not be used.

Temperature setting is the only operation needed. The temperature can be adjusted by using the thermostat button at the back or side of the cabinet. Turn the thermostat button clockwise if the temperature is too high or counter-clockwise if the temperature is too low.

This equipment is intended for the storage and display of packaged ice cream and packaged frozen food.

Electrical requirements

The power supply to the cabinet must conform to all national and local electrical codes. A separate circuit is recommended for each cabinet to prevent loss of product if another appliance on the same circuit causes supply failure.

Note: The supply voltage must not vary more than ten percent from that shown on the data plate located on the rear side of the cabinet. If any doubt – contact an authorized electrician.

Warning

Before removing the plate to the compressor compartment, switch off the appliance and remove the plug from the socket. In the interest of safety, the appliance should only be serviced by authorized persons. The manufacturer refuses to accept responsibility for any injuries or damage sustained due to unauthorized service or alterations to the appliance.

WARNING

Closed containers with fluids containing carbon dioxide must not be put in the freezer, as they may explode.

Operation

Temperature setting is the only operation needed. This temperature can be adjusted by using the thermostat button at the back or side of the cabinet. Start by positioning to figure 5 on the thermostat button opposite the hole in the plate. Place a thermometer approx. 100mm (4") inside the cabinet and check the temperature once it has achieved steady conditions. Turn the thermostat button clockwise if the temperature is too warm or counter-clockwise if the temperature is too cold.

Switching on

Before switching on, the cabinet should be cleaned. Use normal, water-soluble agents suitable for internal cleaning purposes. Once the cabinet has reached the required temperature, it is ready for use.

Maintenance

A layer of frost gradually forms inside the cabinet. When the layer is 3 mm (1/8") thick it should be scraped off using a plastic scraping implement, and removed from the cabinet without switching off. The cabinet is then ready for use again. If the cabinet is dirty inside, it should be switched off at the mains so the layer of frost can melt before cleaning commences.

Breakdown

If the current supply to the cabinet has been disconnected, it should not be reconnected until 6 minutes have elapsed. Unless the delay is observed, the compressor will not be able to start.

The cabinet has been thoroughly tested prior to dispatch; however, if breakdowns occur, please check the following points first:

1. Is the mains current disconnected?
2. Has the fuse blown?
3. Has the mains switch been switched on?
4. Is the plug connected correctly?
5. Is the thermostat button set correctly?

Other defects

Check the following

Compressor not running

Has it been switched off at the mains?
Has the fuse blown?
Is the socket switched on?
Is the plug properly in place?

The temperature is too high

Is the thermostat correctly adjusted?
Thermostat can be adjusted to a lower temperature using procedure previously described
Is the frost layer too thick?

**The compressor runs
Continuously**

Is the thermostat correctly adjusted?
Check and adjust as previously described.
Is the ambient temperature too high?
(Ensure ample air circulation around the appliance.)

If you have checked the above points and the appliance is still not working satisfactorily, please contact your authorized service agent.

Destruction

It is the responsibility of the owner of the appliance to ensure that the destruction of the appliance is carried out in accordance with safety and environmental requirements. VIZ: Doors shall be removed, and together with any locking device, be destroyed separately from the appliance. The refrigeration system shall be removed by an authorized refrigeration engineer and components, including refrigerant and compressor oil, delivered to a recycling center.

The equipment is intended for use in an area where the environmental conditions are controlled and maintained so that the ambient temperature typically does not exceed 80°F (27°C).

STAJAC INDUSTRIES, INC.

3710 Corporex Park Drive
Suite 100
Tampa, FL 33619, U.S.A
Tel: 813-870-0340

**Standard Warranty
Applies Only Within the Continental United States**

Stajac Industries Warrants to the User

FIRST YEAR – The cabinet and all of its parts shall be free of defects in the material and workmanship under normal use and service for a period of one year from the date of installation. Stajac Industries' sole obligation under this warranty shall be limited, at its option, to either repairing or replacing any part of the cabinet determined by Stajac to be defective.

ADDITIONAL FOUR YEARS – The cabinet shall be free of insulation failures and refrigerant leaks within the insulated area of the cabinet for a period of five years from the date of installation or six years from the date of manufacture, whichever occurs first. Stajac's sole obligation under this warranty shall be limited, at its option, to either repairing or replacing any part of the cabinet determined by Stajac not to be as warranted.

The Stajac Standard Warranty and Compressor Warranty do not Cover

LABOR COSTS – Stajac shall not be responsible for any labor costs including but not limited to labor costs required to analyze the condition of the cabinet or its parts or labor costs incurred in the repair or replacement of any portion of the cabinet or its parts.

TRANSPORTATION COSTS – Stajac shall not be responsible for parts or assemblies which, upon inspection, are determined by Stajac to have been subjected to misuse, neglect, alteration, accident, abuse, damage during transit or delivery, or by fire or flood.

CONSEQUENTIAL DAMAGES – IN NO EVENT SHALL STAJAC BE LIABLE FOR SPECIAL, INDIRECT OR CONSEQUENTIAL DAMAGES, INCLUDING WITHOUT LIMITATION, FOOD SPOILAGE OR PRODUCT SPOILAGE CLAIMS, NOR FOR ANY DELAY IN THE PERFORMANCE OF THIS WARRANTY DUE TO CAUSES BEYOND ITS CONTROL.

General

The standard warranty and any service contract related to the STANDARD WARRANTY shall apply only to the products sold and used within the boundaries of the Continental United States.

Users may file warranty claims either directly with Stajac or with immediate seller from whom the cabinet was purchased. All claims must be supported by information concerning the alleged defect and specifically identified by the Serial Number of the cabinet.

THERE ARE NO OTHER WARRANTIES, EXPRESS, IMPLIED, OR STATUTORY, EXCEPT THIS WARRANTY, WHICH IS IN LIEU OF ALL OTHER WARRANTIES INCLUDING, TO THE EXTENT PERMITTED BY LAW, ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE.

FOUR-YEAR WARRANTY CONTRACT (OPTIONAL AT ADDITIONAL COSTS)

In addition to the Stajac Standard Warranty and in accord with the purchase of the optional Four-Year Compressor Contract, Stajac agrees to replace the compressor with a compressor of like or similar design and capacity if it is determined by Stajac that the compressor is inoperative due to defects in factory workmanship or material under normal use and service.

Stajac's obligation under the Four-Year Compressor Warranty Contract shall be limited to a period not to exceed five years from the date of installation. The Four-Year Compressor Warranty does not apply to any part of the cabinet or its finish, nor does it apply to the control relay fan or any electrical component.

Further terms of the contract cannot be considered valid if the compressor has been subjected to an accident, alteration, abuse, misuse, or damaged by flood, fire, or acts of God. The Standard Warranty and the Four-Year Compressor Warranty Contract shall place no liability on Stajac for any labor or labor costs in replacing the compressor, heat exchanger, drier, or replaceable parts of the cabinet. Stajac shall only be obligated to furnish the replacement compressor.

Do Not Drill Holes in Cabinet

Refrigeration tubing and wiring is routed through the cabinet walls. Leaks, wet insulation, or electrical problems caused by drilled holes are not covered by warranty.